



NISOC

نگهداشت و افزایش تولید میدان نفتی بینک
سطح الارض

احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک

I/O LIST FOR CONTROL SYSTEM



شماره پیمان:

053 - 073 - 9184

پروژه

BK

بسته کاری

GCS

صادر کننده

PEDCO

تسهیلات

120

رشته

IN

نوع مدرک

LI

سریال

0002

نسخه

D05

شماره صفحه: 1 از 28

طرح نگهداشت و افزایش تولید 27 مخزن

I/O LIST FOR CONTROL SYSTEM

نگهداشت و افزایش تولید میدان نفتی بینک

Rev.	Date	Purpose of Issue / Status	Prepared by:	Checked by:	Approved by:	CLIENT Approval
D05	JAN.2025	AFC	P.Hajisadeghi	M.Fakharian	S.Faramarzpour	
D04	OCT.2023	AFC	P.Hajisadeghi	M.Fakharian	S.Faramarzpour	
D03	DEC.2022	AFC	P.Hajisadeghi	M.Fakharian	M.Mehrshad	
D02	SEP.2022	AFC	P.Hajisadeghi	M.Fakharian	M.Mehrshad	
D01	MAY.2022	IFA	P.Hajisadeghi	M.Fakharian	M.Mehrshad	
D00	JAN.2022	IFC	P.Hajisadeghi	M.Fakharian	M.Mehrshad	

Class: 1

CLIENT Doc. Number: F0Z-708968

status:

IDC: Inter-Discipline Check

IFC: Issued For Comment

IFA: Issued For Approval

AFD: Approved For Design

AFC: Approved For Construction

AFP: Approved For Purchase

AFQ: Approved For Quotation

IFI: Issued For Information

AB-R: As-Built for CLIENT Review

AB-A: As-Built -Approved



NISOC

نگهداشت و افزایش تولید میدان نفتی بینک
سطح الارض

احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک



I/O LIST FOR CONTROL SYSTEM

شماره پیمان:

053 - 073 - 9184

شماره صفحه: 2 از 28

نسخه	سریال	نوع مدرک	رشته	تسهیلات	صادر کننده	بسته کاری	پروژه
D05	0002	LI	IN	120	PEDCO	GCS	BK

REVISION RECORD SHEET

Page	D00	D01	D02	D03	D04	D05	D06	D07
1	X	X	X	X	X	X		
2	X	X	X	X	X	X		
3	X	X	X	X	X	X		
4	X	X	X	X	X	X		
5	X	X	X	X	X	X		
6	X	X	X	X	X	X		
7	X	X	X	X	X	X		
8	X	X	X	X	X	X		
9	X	X	X	X		X		
10	X	X	X	X		X		
11	X	X	X	X		X		
12	X	X	X	X	X	X		
13		X	X	X	X	X		
14		X	X	X	X	X		
15		X	X	X	X	X		
16		X	X	X	X	X		
17		X	X	X	X	X		
18		X	X	X	X	X		
19		X	X	X	X	X		
20		X	X		X	X		
21			X		X	X		
22			X		X	X		
23			X		X	X		
24			X	X	X	X		
25				X		X		
26						X		
27					X	X		
28					X	X		
29								
30								
31								
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								
51								
52								
53								
54								
55								
56								
57								
58								
59								
60								
61								
62								
63								
64								

Page	D00	D01	D02	D03	D04	D05	D06	D07
65								
66								
67								
68								
69								
70								
71								
72								
73								
74								
75								
76								
77								
78								
79								
80								
81								
82								
83								
84								
85								
86								
87								
88								
89								
90								
91								
92								
93								
94								
95								
96								
97								
98								
99								
100								
101								
102								
103								
104								
105								
106								
107								
108								
109								
110								
111								
112								
113								
114								
115								
116								
117								
118								
119								
120								
121								
122								
123								
124								
125								
126								
127								
128								



NISOC

نگهداشت و افزایش تولید میدان نفتی بینک
سطح الارض

احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک



I/O LIST FOR CONTROL SYSTEM

شماره پیمان:

053 - 073 - 9184

پروژه

BK

بسته کاری

GCS

صادر کننده

PEDCO

تجهیزات

120

رشته

IN

نوع مدرک

LI

سریال

0002

نسخه

D05

شماره صفحه: 3 از 28

D05

REFERENCES:

Symbol & Legend For PFD and P&ID

P&ID - Gas Compression Inlet Gas Pipeline (Binak)

P&ID - Gas Compression Inlet Gas Pipeline (Golghari)

P&ID - Slug Catcher System

P&ID - Gas Compression Inlet Knock Out Drum

P&ID - 1st Stage Gas Compression Suction Drums

P&ID - 1st Stage Gas Compression Compressors

P&ID - 1st Stage Gas Compression Air Coolers

P&ID - 2nd Stage Gas Compression Suction Drums

P&ID - 2nd Stage Gas Compression Compressors

P&ID - 2nd Stage Gas Compression Air Coolers

P&ID - 2nd Stage Gas Compression Discharge Drum

P&ID - Gas Compression Dehydration Package

P&ID - Lean Glycol Storage Tank

P&ID - Instrument & Plant Air System

P&ID - Nitrogen Generation System

P&ID - Close Drain System

P&ID - Corrosion Inhibitor Package

P&ID - Methanol Injection Package

P&ID - LP Flare System

P&ID - Oily Water Sewer

P&ID - Fuel Gas System

P&ID - Diesel Oil System

P&ID - Potable Water System

P&ID - Glycol Sump Drum

P&ID - Fire Water Network

P&ID - Total Flooding System For Extension of Existing Elect. Building

P&ID - Gas Pipeline (to Siahmakan G.I. Station)

Data Sheets For ESD Console/F&G Matrix Panel

ESD Level Hierarchy

Electrical I/O Signal List

BK-GCS-PEDCO-120-PR-PI-0001_D06

BK-GCS-PEDCO-120-PR-PI-0002_D08

BK-GCS-PEDCO-120-PR-PI-0003_D08

BK-GCS-PEDCO-120-PR-PI-0004_D10

BK-GCS-PEDCO-120-PR-PI-0005_D10

BK-GCS-PEDCO-120-PR-PI-0006_D10

BK-GCS-PEDCO-120-PR-PI-0007_D09

BK-GCS-PEDCO-120-PR-PI-0008_D10

BK-GCS-PEDCO-120-PR-PI-0009_D09

BK-GCS-PEDCO-120-PR-PI-0010_D08

BK-GCS-PEDCO-120-PR-PI-0011_D10

BK-GCS-PEDCO-120-PR-PI-0012_D09

BK-GCS-PEDCO-120-PR-PI-0013_D09

BK-GCS-PEDCO-120-PR-PI-0014_D09

BK-GCS-PEDCO-120-PR-PI-0015_D08

BK-GCS-PEDCO-120-PR-PI-0016_D08

BK-GCS-PEDCO-120-PR-PI-0017_D09

BK-GCS-PEDCO-120-PR-PI-0018_D09

BK-GCS-PEDCO-120-PR-PI-0019_D07

BK-GCS-PEDCO-120-PR-PI-0020_D9

BK-GCS-PEDCO-120-PR-PI-0021_D05

BK-GCS-PEDCO-120-PR-PI-0022_D09

BK-GCS-PEDCO-120-PR-PI-0023_D08

BK-GCS-PEDCO-120-PR-PI-0024_D08

BK-GCS-PEDCO-120-PR-PI-0025_D09

BK-GCS-PEDCO-120-SA-PI-0001_D06

BK-GCS-PEDCO-120-SA-PI-0002_D03

BK-PPL-PEDCO-320-PR-PI-0001_D05

BK-GCS-PEDCO-120-IN-DT-0017_D04

BK-GCS-PEDCO-120-IN-DG-0003_D02

BK-GCS-PEDCO-120-EL-LI-0005-D03

NOTES:

NOTE 1: ALL ANALOUGE TRANSMITTERS SHALL BE CONSIDERED INTRINSICALLY SAFE (EEXIA) & ALL OF DIGITAL TRANSMITTERS ARE NON INTRINSICALLY SAFE (EEXD).

NOTE 2: I/O CARDS & ACCESSORIES SHALL BE SELECTED IN ACCORDANCE WITH "SPECIFICATION FOR CONTROL SYSTEM".

NOTE 3: DEHYDRATION PACKAGE (PK-2101) HAS ITS OWN UCP AND ALL I/Os REQUIRED FOR DEHYDRATION PACKAGE (PK-2101) WILL BE FINALIZED LATER. FOR MORE DETAILS REFER TO THE PACKAGE DOCUMENTS.

NOTE 4: THE COMMUNICATION BETWEEN DCS AND ALL PACKAGES SHALL BE CONSIDERED BY DCS VENDOR INCLUDING UCP-C-2101A, UCP-C-2101B, UCP-C-2101C (3 UCP FOR GAS COMPRESSORS), PK-2101 (1 UCP FOR DEHYDRATION PACKAGE), PK-AC-2203 A/B (2 UCP FOR AIR COMPRESSOR & DRYER PACKAGE), AND PK-G-2204 (1 UCP FOR NITROGEN GENERATION) PACKAGE. ALSO THE PROPER COMMUNICATION FOR ELECTRICAL PART (SUBSTATION) SHALL BE CONSIDERED. THE RELATED SIGNALS ARE GIVEN IN SHEET "DATA-LINK SOFTWARE".

NOTE 5: THIS TABLE SHOWS SIGNALS BETWEEN FIELD AND GAS COMPRESSORS' UCPS. THESE INSTRUMENTS DO NOT HAVE HARDWARE SIGNALS TO GENERAL DCS AND/OR ESD. THE COMPLETE NEEDED SIGNALS OF GAS COMPRESSORE HAVE BEEN CONSIDERED IN UCP-C-2101A, UCP-C-2101B, AND UCP-C-2101C SEPARATELY. FOR MORE DETAILS REFER TO P&ID OF COMPRESSOR VENDOR (HAVAYAR).

NOTE 6: ALL ESD I/Os SHALL BE TRANSMITTED TO THE DCS SYSTEM BY SOFTWARE DATA-LINK.

NOTE 7: ALL SERIAL DATA LINK OF THE PACKAGES WILL BE FINILIZED AFTER VENDOR DATA.



NISOC

نگهداشت و افزایش تولید میدان نفتی بینک
سطح الارض

احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک



I/O LIST FOR CONTROL SYSTEM

شماره پیمان:

053 - 073 - 9184

پروژه

BK

بسته کاری

GCS

صادر کننده

PEDCO

تجهیزات

120

رشته

IN

نوع مدرک

LI

سریال

0002

نسخه

D05

شماره صفحه: 4 از 28

DCS I/O SUMMERY COUNT

D05

ITEM	I/O TYPE	IS/NIS	R/NR	DESCRIPTION	QTY OF SIGNALS	QTY (+20% SPARE)	REMARKS
1	AI-IS-R	IS	R	ANALOGUE INPUT HARDWARE SIGNAL (INTRINSICALLY SAFE, REDUNDANT)	47	57	NOTES 1,2,3
2	AI-IS-NR	IS	NR	ANALOGUE INPUT HARDWARE SIGNAL (INTRINSICALLY SAFE, NON-REDUNDANT)	32	39	NOTES 1,2,3
3	AO-IS-R	IS	R	ANALOGUE OUTPUT HARDWARE SIGNAL (INTRINSICALLY SAFE, REDUNDANT)	23	28	NOTES 1,2,3
4	AO-IS-NR	IS	NR	ANALOGUE OUTPUT HARDWARE SIGNAL (INTRINSICALLY SAFE, NON-REDUNDANT)	0	0	NOTES 1,2,3
5	DI-NIS-R	NIS	R	DIGITAL INPUT HARDWARE SIGNAL (NON INTRINSICALLY SAFE, REDUNDANT)	9	11	NOTES 1,2,3
6	DI-NIS-NR	NIS	NR	DIGITAL INPUT HARDWARE SIGNAL (NON INTRINSICALLY SAFE, NON-REDUNDANT)	198	238	NOTES 1,2,3
7	DO-NIS-R	NIS	R	DIGITAL OUTPUT HARDWARE SIGNAL (NON INTRINSICALLY SAFE, REDUNDANT)	18	22	NOTES 1,2,3
8	DO-NIS-NR	NIS	NR	DIGITAL OUTPUT HARDWARE SIGNAL (NON INTRINSICALLY SAFE, NON-REDUNDANT)	61	74	NOTES 1,2,3

NOTE 8 : The estimated I/O (No.100) for DEHYDRATION package shall be added to above DCS I/O summary. (refer to note 3).

UCP I/O SUMMERY COUNT (NOTE 5)

ITEM	I/O TYPE	IS/NIS	R/NR	DESCRIPTION	QTY OF SIGNALS	QTY (+20% SPARE)	REMARKS
1	AI-IS-R	IS	R	ANALOGUE INPUT HARDWARE SIGNAL (INTRINSICALLY SAFE, REDUNDANT)	39	47	NOTES 1,2,3
2	AI-IS-NR	IS	NR	ANALOGUE INPUT HARDWARE SIGNAL (INTRINSICALLY SAFE, NON-REDUNDANT)	0	0	NOTES 1,2,3
3	AO-IS-R	IS	R	ANALOGUE OUTPUT HARDWARE SIGNAL (INTRINSICALLY SAFE, REDUNDANT)	3	4	NOTES 1,2,3
4	AO-IS-NR	IS	NR	ANALOGUE OUTPUT HARDWARE SIGNAL (INTRINSICALLY SAFE, NON-REDUNDANT)	0	0	NOTES 1,2,3
5	DI-NIS-NR	NIS	NR	DIGITAL INPUT HARDWARE SIGNAL (NON INTRINSICALLY SAFE, NON-REDUNDANT)	12	15	NOTES 1,2,3
6	DO-NIS-R	NIS	R	DIGITAL OUTPUT HARDWARE SIGNAL (NON INTRINSICALLY SAFE, REDUNDANT)	0	0	NOTES 1,2,3
7	DO-NIS-NR	NIS	NR	DIGITAL OUTPUT HARDWARE SIGNAL (NON INTRINSICALLY SAFE, NON-REDUNDANT)	9	11	NOTES 1,2,3

ABBREVIATIONS:

I/O	INPUT / OUTPUT	DCS:	DISTRIBUTED CONTROL SYSTEM
DI:	DIGITAL INPUT SIGNAL	ESD:	EMERGENCY SHUT DOWN SYSTEM
DO:	DIGITAL OUTPUT SIGNAL	F&G	FIRE AND GAS CONTROL SYSTEM
AI:	ANALOGUE INPUT SIGNAL	MCC:	MOTOR CONTROL CENTER
AO:	ANALOGUE OUTPUT SIGNAL	IRP:	INTERPOSING RELAY PANEL
IND:	INDICATION	CH:	CHANNEL
STA:	STATUS	ADD:	ADDRESS
COM:	COMMAND	TB:	TERMINAL BLOCK
IS	INTRINSICALLY SAFE	R:	REDUNDANT
NIS	NON INTRINSICALLY SAFE	NR:	NON-REDUNDANT

 NISOC شماره پیمان: 053 - 073 – 9184				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک I/O LIST FOR CONTROL SYSTEM <table><tr><td>پروژه</td><td>بسته کاری</td><td>صادر کننده</td><td>تهیهات</td><td>رشته</td><td>نوع مدرک</td><td>سریال</td><td>نسخه</td></tr><tr><td>BK</td><td>GCS</td><td>PEDCO</td><td>120</td><td>IN</td><td>LI</td><td>0002</td><td>D05</td></tr></table>								پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه	BK	GCS	PEDCO	120	IN	LI	0002	D05	 شماره صفحه: 5 از 28			
پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه																								
BK	GCS	PEDCO	120	IN	LI	0002	D05																								
I/O List For Control System																															
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.								
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.										
1	FCV-2101	Flow Control Valve	TO INLET K.O. DRUM (V-2105)	BK-GCS-PEDCO-120-PR-PI-0002	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X								
2	FIT-2101	Flow Transmitter	TO INLET K.O. DRUM (V-2105)	BK-GCS-PEDCO-120-PR-PI-0002	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X			X								
3	TIT-2102	Flow Transmitter	TO INLET K.O. DRUM (V-2105)	BK-GCS-PEDCO-120-PR-PI-0002	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
4	PIT-2102	Pressure Transmitter	TO INLET K.O. DRUM (V-2105)	BK-GCS-PEDCO-120-PR-PI-0002	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*			X			X								
5	EZSC-2101	ESDV Limit Switch Close	TO INLET K.O. DRUM (V-2105)	BK-GCS-PEDCO-120-PR-PI-0002	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
6	EZSO-2101	ESDV Limit Switch Open	TO INLET K.O. DRUM (V-2105)	BK-GCS-PEDCO-120-PR-PI-0002	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
7	FCV-2102	Flow Control Valve	TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X								
8	FIT-2102	Flow Transmitter	TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X			X								
9	TIT-2104	Temperature Transmitter	TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
10	PIT-2104	Pressure Transmitter	TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*			X			X								
11	EZSC-2102	ESDV Limit Switch Close	TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	ESD	*	*	*	*	*	*	*	*	*	*						X								
12	EZSO-2102	ESDV Limit Switch Open	TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	ESD	*	*	*	*	*	*	*	*	*	*						X								
13	ZA-2004A	PIG Signaller	TO PR-2002	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
14	ZA-2004B	PIG Signaller	TO PR-2002	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
15	ZA-2102B	PIG Signaller	TO PR-2002	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
16	HSL-2003	Hand Switch Local/Remot (MOV-2003)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
17	XF-2003	Fault Feedback (MOV-2003)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
18	MZTO-2003	Torque Limit Switch Open (MOV-2003)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
19	MZTC-2003	Torque Limit Switch Close (MOV-2003)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
20	MZIO-2003	Limit Switch Open (MOV-2003)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
21	MZIC-2003	Limit Switch Close (MOV-2003)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
22	MSO-2003	Valve Open Command (MOV-2003)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X								
23	MSC-2003	Valve Close Command (MOV-2003)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X								
24	HSL-2004	Hand Switch Local/Remot (MOV-2004)	GAS FROM GOLKHARI/TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
25	XF-2004	Fault Feedback (MOV-2004)	GAS FROM GOLKHARI/TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
26	MZTO-2004	Torque Limit Switch Open (MOV-2004)	GAS FROM GOLKHARI/TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
27	MZTC-2004	Torque Limit Switch Close (MOV-2004)	GAS FROM GOLKHARI/TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
28	MZIO-2004	Limit Switch Open Status (MOV-2004)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
29	MZIC-2004	Limit Switch Close Status (MOV-2004)	TO PR-2102	BK-GCS-PEDCO-120-PR-PI-0003	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*						X								
30	MSO-2004	Valve Open Command (MOV-2004)	GAS FROM GOLKHARI/TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X								

 NISOC				تگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																				
شماره پیمان: 053 - 073 – 9184				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 6 از 28												
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه													
				BK	GCS	PEDCO	120	IN	LI	0002	D05													
I/O List For Control System																								
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.			
31	MSC-2004	Valve Close Command (MOV-2004)	GAS FROM GOLKHARI/TO SLUG CATCHER (V-2104)	BK-GCS-PEDCO-120-PR-PI-0003	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*							X		
32	PIT-2112	Pressure Indicator Transmitter	V-2104	BK-GCS-PEDCO-120-PR-PI-0004 (1 of 2)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X			
33	PDIT-2111	Diff. Pressure Indicator Transmitter	V-2104	BK-GCS-PEDCO-120-PR-PI-0004 (1 of 2)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X				X			
34	LIT-2111	Level Indicator Transmitter (DP)	V-2104	BK-GCS-PEDCO-120-PR-PI-0004 (1 of 2)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X			
35	EZSO-2112	ESDV Limit Switch Open	From P-2101A/B TO Flare Header	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
36	EZSC-2112	ESDV Limit Switch Close	From P-2101A/B TO Flare Header	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
37	FIT-2111	Flow Indicator Transmitter	From P-2101A/B TO Flare Header	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*						X			
38	FCV-2111	Flow Control Valve	From P-2101A/B TO Flare Header	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*							X		
39	PIT-2114	Pressure Indicator Transmitter	From P-2101A/B TO Flare Header	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X				X			
40	XL-2111A	Local / Remote Status	P-2101A	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
41	XR-2111A	Running/Stop Status	P-2101A	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
42	XF-2111A	Fault Status	P-2101A	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
43	XSP-2111A	STOP Command	P-2101A	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
44	XL-2111B	Local / Remote Status	P-2101B	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
45	XR-2111B	Running/Stop Status	P-2101B	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
46	XF-2111B	Fault Status	P-2101B	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
47	XSP-2111B	STOP Command	P-2101B	BK-GCS-PEDCO-120-PR-PI-0004 (2 of 2)	DO-NIS-NR	DCS	IRP	*	*	*	*	*	*	*	*							X		
48	TIT-2112	Temperature Indicator Transmitter	FROM SLUG CATCHER DRUM (V-2104) /Inlet Knock Out Drum (V-2105)	BK-GCS-PEDCO-120-PR-PI-0005	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X			
49	PIT-2117	Pressure Indicator Transmitter	Knock Out Drum (V-2105)	BK-GCS-PEDCO-120-PR-PI-0005	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X			
50	PDIT-2112	Diff. Pressure Indicator Transmitter	Knock Out Drum (V-2105)	BK-GCS-PEDCO-120-PR-PI-0005	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X				X			
51	EZSO-2113	ESDV Limit Switch Open	Outlet (V-2105) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0005	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
52	EZSC-2113	ESDV Limit Switch Close	Outlet (V-2105) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0005	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
53	LIT-2119	Level Indicator Transmitter	V-2105	BK-GCS-PEDCO-120-PR-PI-0005	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X			
54	LCV-2114	Level Control Valve	Outlet (V-2105) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0005	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*							X		
55	BZSO-2110	Blowdown Limit Switch Open	From V-2105 to LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0005	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Added
56	BZSC-2110	Blowdown Limit Switch Close	From V-2105 to LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0005	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Added
57	PIT-2121A	Pressure Indicator Transmitter	Outlet V-2101-A /to 1st Stage Compressore (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*			X			X			
58	PI-2121A	Pressure Control Valve	Outlet V-2101-A /to 1st Stage Compressore (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	AO-IS-R	DCS	UCP-GC-2101A	*	*	*	*	*	*	*	*							X		
59	PDIT-2121A	Diff. Pressure Indicator Transmitter	V-2101-A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X				X			
60	LIT-2121A	Level Indicator Transmitter	V-2101-A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X			

 NISOC شماره پیمان: 053 - 073 – 9184				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک								 											
				I/O LIST FOR CONTROL SYSTEM																			
				پروژه	بسته کاری	صادر کننده	تجهیزات	رشته	نوع مدرک	سریال	نسخه	شماره صفحه: 7 از 28											
				BK	GCS	PEDCO	120	IN	LI	0002	D05												
I/O List For Control System																							
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet		ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA			COM.
61	PSOV-2121A	Solenoid Valve	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Added
62	XZSC-2121A	Limit Switch Close	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
63	XZSO-2121A	Limit Switch Open	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
64	PSOV-2122A	Solenoid Valve	Outlet (V-2101-A) To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
65	XZSC-2122A	Limit Switch Close	Outlet (V-2101-A) To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
66	XZSO-2122A	Limit Switch Open	Outlet (V-2101-A) To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
67	PIT-2121B	Pressure Indicator Transmitter	Outlet V-2101-B /to 1st Stage Compressor (C-2101B)	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*			X		X			
68	PI-2121B	Pressure Control Valve	Outlet V-2101-A /to 1st Stage Compressor (C-2101B)	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	AO-IS-R	DCS	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		
69	PDIT-2121B	Diff. Pressure Indicator Transmitter	V-2101-B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X			X			
70	LIT-2121B	Level Indicator Transmitter	V-2101-B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
71	PSOV-2121B	Solenoid Valve	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Added
72	XZSC-2121B	Limit Switch Close	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
73	XZSO-2121B	Limit Switch Open	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
74	PSOV-2122B	Solenoid Valve	Outlet (V-2101-B) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
75	XZSC-2122B	Limit Switch Close	Outlet (V-2101-B) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
76	XZSO-2122B	Limit Switch Open	Outlet (V-2101-B) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
77	PIT-2121C	Pressure Indicator Transmitter	Outlet V-2101-C /to 1st Stage Compressor (C-2101C)	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*			X		X			
78	PI-2121C	Pressure Control Valve	Outlet V-2101-A /to 1st Stage Compressor (C-2101C)	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	AO-IS-R	DCS	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		
79	PDIT-2121C	Diff. Pressure Indicator Transmitter	V-2101-C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X			X			
80	LIT-2121C	Level Indicator Transmitter	V-2101-C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
81	PSOV-2121C	Solenoid Valve	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Added

 NISOC			تنگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک						 														
شماره پیمان: 053 - 073 - 9184			I/O LIST FOR CONTROL SYSTEM									شماره صفحه: 8 از 28											
			پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه													
			BK	GCS	PEDCO	120	IN	LI	0002	D05													
I/O List For Control System																							
ITEM	TAG	DESCRIPTION	SERVICE	P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.		
82	XZSC-2121C	Limit Switch Close	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Added
83	XZSO-2121C	Limit Switch Open	From 1st stage Gas Compression suction manifold to 1st stage Gas Compression suction drum train C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Added
84	PSOV-2122C	Solenoid Valve	Outlet (V-2101-C) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
85	XZSC-2122C	Limit Switch Close	Outlet (V-2101-C) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		
86	XZSO-2122C	Limit Switch Open	Outlet (V-2101-C) /To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		
87	TIT-2121A	Temperature Indicator Transmitter	From 1ST Stage Gas Comp. Suction Drum (V-2101A) /To C-2101-A	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X		
-	XSS-2124A	Start Permission	1ST Gas Compressor Train#A (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	DI-NIS-NR	UCP-GC-2101A	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
88	XSS-2126A	Request Start Permission from C-2101A	1ST Gas Compressor Train#A (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	DI-NIS-R	UCP-GC-2101A	DCS	*	*	*	*	*	*	*	*						X		D05 Added
89	XR-2124A	Running/Stop Status	1ST Gas Compressor Train#A (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	DI-NIS-R	UCP-GC-2101A	DCS	*	*	*	*	*	*	*	*						X		D05 Added
90	XSS-2123A	Start Permission	1ST Gas Compressor Train#A (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	DI-NIS-R	DCS	UCP-GC-2101A	*	*	*	*	*	*	*	*						X		D05 Modified
-	XSP-2123A	Stop Command	1ST Gas Compressor Train#A (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	DO-NIS-NR	DCS	UCP-GC-2101A	*	*	*	*	*	*	*	*						X		D05 Deleted
-	BZSO-2122A	Blowdown Limit Switch Open	C-2101-A	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
-	BZSC-2122A	Blowdown Limit Switch Close	C-2101-A	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
91	TIT-2121B	Temperature Indicator Transmitter	From 1ST Stage Gas Comp. Suction Drum (V-2101B) /To C-2101-B	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X		
-	XSS-2124B	Start Permission	1ST Gas Compressor Train#B (C-2101B)	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	DI-NIS-NR	UCP-GC-2101B	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
92	XSS-2126B	Request Start Permission from C-2101B	1ST Gas Compressor Train#A (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	DI-NIS-R	UCP-GC-2101B	DCS	*	*	*	*	*	*	*	*						X		D05 Added
93	XR-2124B	Running/Stop Status	1ST Gas Compressor Train#B (C-2101B)	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	DI-NIS-R	UCP-GC-2101B	DCS	*	*	*	*	*	*	*	*						X		D05 Added
94	XSS-2123B	Start Permission	1ST Gas Compressor Train#B (C-2101B)	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	DI-NIS-R	DCS	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Modified
-	XSP-2123B	Stop Command	1ST Gas Compressor Train#B (C-2101B)	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	DO-NIS-NR	DCS	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Deleted
-	BZSO-2122B	Blowdown Limit Switch Open	C-2101-B	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
-	BZSC-2122B	Blowdown Limit Switch Close	C-2101-B	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
95	TIT-2121C	Temperature Indicator Transmitter	From 1ST Stage Gas Comp. Suction Drum (V-2101C) /To C-2101-C	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X		
-	XSS-2124C	Start Permission	1ST Gas Compressor Train#C (C-2101C)	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	DI-NIS-NR	UCP-GC-2101C	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
96	XSS-2126C	Request Start Permission from C-2101C	1ST Gas Compressor Train#A (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	DI-NIS-R	UCP-GC-2101C	DCS	*	*	*	*	*	*	*	*						X		D05 Added
97	XR-2124C	Running/Stop Status	1ST Gas Compressor Train#C (C-2101C)	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	DI-NIS-R	UCP-GC-2101C	DCS	*	*	*	*	*	*	*	*						X		D05 Added
98	XSS-2123C	Start Permission	1ST Gas Compressor Train#C (C-2101C)	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	DI-NIS-R	DCS	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		D05 Modified
-	XSP-2123C	Stop Command	1ST Gas Compressor Train#C (C-2101C)	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	DO-NIS-NR	DCS	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		D05 Deleted
-	BZSO-2122C	Blowdown Limit Switch Open	C-2101-C	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
-	BZSC-2122C	Blowdown Limit Switch Close	C-2101-C	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Deleted
99	XF-2121A	Fault Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) / (AC-2121A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X		

 NISOC شماره پیمان: 053 - 073 – 9184				تنگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک I/O LIST FOR CONTROL SYSTEM <table><tr><td>پروژه</td><td>بسته کاری</td><td>صادر کننده</td><td>تهیهات</td><td>رشته</td><td>نوع مدرک</td><td>سریال</td><td>نسخه</td></tr><tr><td>BK</td><td>GCS</td><td>PEDCO</td><td>120</td><td>IN</td><td>LI</td><td>0002</td><td>D05</td></tr></table>								پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه	BK	GCS	PEDCO	120	IN	LI	0002	D05	 شماره صفحه: 9 از 28											
پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه																																
BK	GCS	PEDCO	120	IN	LI	0002	D05																																
I/O List For Control System																																							
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.																
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.																		
100	XR-2121A	Running/Stop Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2121A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
101	XL-2121A	Local / Remote Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2121A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
102	XSP-2121A	Stop Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2121A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified															
103	XSS-2121A	Start Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2121A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified															
104	XF-2122A	Fault Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2122A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
105	XR-2122A	Running/Stop Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2122A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DI-NIS-NR		DCS	*	*	*	*	*	*	*	*						X																		
106	XL-2122A	Local / Remote Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2122A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
107	XSP-2122A	Stop Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2122A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified															
108	XSS-2122A	Start Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A) /(AC-2122A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified															
109	TIT-2126A	Temperature Indicator Transmitter	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X																		
110	TY-2122A	Cooler Actuator Positioner	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-A)	BK-GCS-PEDCO-120-PR-PI-0008 (1 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*							X																	
111	XF-2121B	Fault Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2121B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
112	XR-2121B	Running/Stop Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2121B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
113	XL-2121B	Local / Remote Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2121B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
114	XSP-2121B	Stop Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2121B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified															
115	XSS-2121B	Start Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2121B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified															
116	XF-2122B	Fault Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2122B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
117	XR-2122B	Running/Stop Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2122B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
118	XL-2122B	Local / Remote Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2122B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		
119	XSP-2122B	Stop Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2122B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified															
120	XSS-2122B	Start Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B) /(AC-2122B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified															
121	TIT-2126B	Temperature Indicator Transmitter	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X																		
122	TY-2122B	Cooler Actuator Positioner	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-B)	BK-GCS-PEDCO-120-PR-PI-0008 (2 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*							X																	
123	XF-2121C	Fault Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2121C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X																		

 NISOC				تگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																			
شماره پیمان: 053 - 073 - 9184				I/O LIST FOR CONTROL SYSTEM										شماره صفحه: 10 از 28									
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدارک	سریال	نسخه												
				BK	GCS	PEDCO	120	IN		LI		0002	D05										
I/O List For Control System																							
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet		ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA			COM.
124	XR-2121C	Running/Stop Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2121C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
125	XL-2121C	Local / Remote Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2121C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
126	XSP-2121C	Stop Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2121C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*						X		D05 Modified
127	XSS-2121C	Start Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2121C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*						X		D05 Modified
128	XF-2122C	Fault Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2122C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
129	XR-2122C	Running/Stop Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2122C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
130	XL-2122C	Local / Remote Status	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2122C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
131	XSP-2122C	Stop Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2122C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*						X		D05 Modified
132	XSS-2122C	Start Command	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C) /(AC-2122C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*						X		D05 Modified
133	TIT-2126C	Temperature Indicator Transmitter	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
134	TY-2122C	Cooler Actuator Positioner	FROM 1ST Stage Gas Compressor Air Coolers (AE-2101-C)	BK-GCS-PEDCO-120-PR-PI-0008 (3 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		
135	PDIT-2131A	Diff. Pressure Indicator Transmitter	V-2102-A	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X			X			
136	LIT-2131A	Level Indicator Transmitter	V-2102-A	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
137	PSOV-2131A	Solenoid Valve	FROM V-2102-A / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
138	XZSC-2131A	Limit Switch Close	FROM V-2102-A / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
139	XZSO-2131A	Limit Switch Open	FROM V-2102-A / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
140	BZSO-2134A	Blowdown Limit Switch Open	From V-2102-A to LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
141	BZSC-2134A	Blowdown Limit Switch Close	From V-2102-A to LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
142	PDIT-2131B	Diff. Pressure Indicator Transmitter	V-2102-B	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X			X			
143	LIT-2131B	Level Indicator Transmitter	V-2102-B	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
144	PSOV-2131B	Solenoid Valve	FROM V-2102-B / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
145	XZSC-2131B	Limit Switch Close	FROM V-2102-B / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
146	XZSO-2131B	Limit Switch Open	FROM V-2102-B / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
147	BZSO-2134B	Blowdown Limit Switch Open	From V-2102-B to LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
148	BZSC-2134B	Blowdown Limit Switch Close	From V-2102-B to LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
149	PDIT-2131C	Diff. Pressure Indicator Transmitter	V-2102-C	BK-GCS-PEDCO-120-PR-PI-0009 (3 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X			X			
150	LIT-2131C	Level Indicator Transmitter	V-2102-C	BK-GCS-PEDCO-120-PR-PI-0009 (3 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
151	PSOV-2131C	Solenoid Valve	FROM V-2102-C / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (3 of 3)	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
152	XZSC-2131C	Limit Switch Close	FROM V-2102-C / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			

 NISOC				تنگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																							
شماره پیمان: 053 - 073 – 9184				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 11 از 28															
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه																
				BK	GCS	PEDCO	120	IN	LI	0002	D05																
I/O List For Control System																											
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.				
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.						
153	XZSO-2131C	Limit Switch Open	FROM V-2102-C / To Close Drain Header	BK-GCS-PEDCO-120-PR-PI-0009 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*					X					
154	BZSO-2134C	Blowdown Limit Switch Open	From V-2102-C to LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*					X			D05 Added		
155	BZSC-2134BC	Blowdown Limit Switch Close	From V-2102-C to LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*					X			D05 Added		
156	TIT-2131A	Temperature Indicator Transmitter	From 2ND Stage Gas Comp. Suction Drum (V-2102A) /To C-2102-A	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X					
157	TIT-2131B	Temperature Indicator Transmitter	From 2ND Stage Gas Comp. Suction Drum (V-2102A) /To C-2102-A	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X					
158	TIT-2131C	Temperature Indicator Transmitter	From 2ND Stage Gas Comp. Suction Drum (V-2102A) /To C-2102-A	BK-GCS-PEDCO-120-PR-PI-0010 (3 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X					
159	XF-2131A	Fault Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2131A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
160	XR-2131A	Running/Stop Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2131A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
161	XL-2131A	Local / Remote Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2131A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
162	XSP-2131A	Stop Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2131A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
163	XSS-2131A	Start Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2131A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
164	XF-2132A	Fault Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2132A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
165	XR-2132A	Running/Stop Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2132A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
166	XL-2132A	Local / Remote Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2132A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
167	XSP-2132A	Stop Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2132A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
168	XSS-2132A	Start Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)/(AC-2132A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
169	TIT-2135A	Temperature Indicator Transmitter	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X					
170	TY-2132A	Cooler Actuator Positioner	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-A)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X				
171	PIT-2135A	Pressure Indicator Transmitter	From AE-2102-A /TO GAS COMPRESSION DISCHARGE DRUM (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X					
172	PCV-2135A	Pressure Control Valve	From AE-2102-A /TO GAS COMPRESSION DISCHARGE DRUM (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X				
173	PSOV-2132A	Solenoid Valve	From AE-2102-A to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X		D05 Added		
174	BZSC-2132A	Blowdown Limit Switch Close	From AE-2102-A to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*	*	*					X			D05 Added		

 NISOC				تگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک							 													
شماره پیمان: 053 - 073 – 9184				I/O LIST FOR CONTROL SYSTEM							شماره صفحه: 12 از 28													
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال											نسخه			
				BK	GCS	PEDCO	120	IN	LI	0002	D05													
I/O List For Control System																								
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	INDSTA	COM.			
175	BZSO-2132A	Blowdown Limit Switch Open	From AE-2102-A to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Added
176	PSOV-2133A	Solenoid Valve	From AE-2102-A to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*							X		D05 Added
177	XZSC-2133A	Limit Switch Close	From AE-2102-A to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Added
178	XZSO-2133A	Limit Switch Open	From AE-2102-A to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Added
179	XF-2131B	Fault Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2131B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
180	XR-2131B	Running/Stop Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2131B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
181	XL-2131B	Local / Remote Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2131B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
182	XSP-2131B	Stop Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2131B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
183	XSS-2131B	Start Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2131B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
184	XF-2132B	Fault Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2132B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
185	XR-2132B	Running/Stop Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2132B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
186	XL-2132B	Local / Remote Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2132B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X			
187	XSP-2132B	Stop Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2132B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
188	XSS-2132B	Start Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)/(AC-2132B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
189	TIT-2135B	Temperature Indicator Transmitter	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X			
190	TY-2132B	Cooler Actuator Positioner	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-B)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*							X		
191	PIT-2135B	Pressure Indicator Transmitter	From AE-2102-B /TO GAS COMPRESSION DISCHARGE DRUM (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X			
192	PCV-2135B	Pressure Control Valve	From AE-2102-B /TO GAS COMPRESSION DISCHARGE DRUM (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*							X		
193	PSOV-2132B	Solenoid Valve	From AE-2102-B to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*							X		D05 Added
194	BZSC-2132B	Blowdown Limit Switch Close	From AE-2102-B to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Added
195	BZSO-2132B	Blowdown Limit Switch Open	From AE-2102-B to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X			D05 Added

 NISOC				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																				
شماره پیمان: 053 - 073 - 9184				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 13 از 28												
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه													
				BK	GCS	PEDCO	120	IN	LI	0002	D05													
I/O List For Control System																								
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.			
196	PSOV-2133B	Solenoid Valve	From AE-2102-B to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*							X		D05 Added
197	XZSC-2133B	Limit Switch Close	From AE-2102-B to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*							X		D05 Added
198	XZSO-2133B	Limit Switch Open	From AE-2102-B to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*							X		D05 Added
199	XF-2131C	Fault Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2131C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*							X		
200	XR-2131C	Running/Stop Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2131C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*							X		
201	XL-2131C	Local / Remote Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2131C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*							X		
202	XSP-2131C	Stop Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2131C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
203	XSS-2131C	Start Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2131C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
204	XF-2132C	Fault Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2132C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*							X		
205	XR-2132C	Running/Stop Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2132C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*							X		
206	XL-2132C	Local / Remote Status	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2132C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*							X		
207	XSP-2132C	Stop Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2132C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
208	XSS-2132C	Start Command	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)/(AC-2132C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X		D05 Modified
209	TIT-2135C	Temperature Indicator Transmitter	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X				X		
210	TY-2132C	Cooler Actuator Positioner	FROM 2ND Stage Gas Compressor Air Coolers (AE-2102-C)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*							X		
211	PIT-2135C	Pressure Indicator Transmitter	From AE-2102-C /TO GAS COMPRESSION DISCHARGE DRUM (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X				X		
212	PCV-2135C	Pressure Control Valve	From AE-2102-C /TO GAS COMPRESSION DISCHARGE DRUM (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*							X		
213	PSOV-2132C	Solenoid Valve	From AE-2102-C to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*							X		D05 Added
214	BZSC-2132C	Blowdown Limit Switch Close	From AE-2102-C to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*							X		D05 Added
215	BZSO-2132C	Blowdown Limit Switch Open	From AE-2102-C to LP Flare header	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*							X		D05 Added

 NISOC				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																			
شماره پیمان: 053 - 073 – 9184				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 14 از 28											
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه												
				BK	GCS	PEDCO	120	IN	LI	0002	D05												
I/O List For Control System																							
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.		
216	PSOV-2133C	Solenoid Valve	From AE-2102-C to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Added
217	XZSC-2133C	Limit Switch Close	From AE-2102-C to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
218	XZSO-2133C	Limit Switch Open	From AE-2102-C to Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Added
219	PDIT-2141	Diff. Pressure Indicator Transmitter	V-2103	BK-GCS-PEDCO-120-PR-PI-0012	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X			X			
220	LIT-2141	Level Indicator Transmitter	V-2103	BK-GCS-PEDCO-120-PR-PI-0012	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
221	PSOV-2144	Solenoid Valve	From V-2103 To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0012	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
222	XZSC-2144	Limit Switch Close	From V-2103/ To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0012	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
223	XZSO-2144	Limit Switch Open	From V-2103/ To Closed Drain Header	BK-GCS-PEDCO-120-PR-PI-0012	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
224	BZSC-2141	Blowdown Limit Switch Close	From V-2103/ To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0012	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
225	BZSO-2141	Blowdown Limit Switch Open	From V-2103/ To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0012	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
226	PSOV-2142	Solenoid Valve	From V-2103 To Dehydration Package (PK-2101)	BK-GCS-PEDCO-120-PR-PI-0012	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
227	XZSC-2142	Limit Switch Close	From V-2103/ To Dehydration Package (PK-2101)	BK-GCS-PEDCO-120-PR-PI-0012	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
228	XZSO-2142	Limit Switch Open	From V-2103/ To Dehydration Package (PK-2101)	BK-GCS-PEDCO-120-PR-PI-0012	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
229	PSOV-2143	Solenoid Valve	From V-2103 To Dehydration Package (PK-2101)	BK-GCS-PEDCO-120-PR-PI-0012	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
230	XZSC-2143	Limit Switch Close	From V-2103/ To Dehydration Package (PK-2101)	BK-GCS-PEDCO-120-PR-PI-0012	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
231	XZSO-2143	Limit Switch Open	From V-2103/ To Dehydration Package (PK-2101)	BK-GCS-PEDCO-120-PR-PI-0012	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
232	PDIT-2143	Diff. Pressure Indicator Transmitter	From V-2103/ To Dehydration Package (PK-2101)	BK-GCS-PEDCO-120-PR-PI-0012	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
233	BZSC-2151	Blowdown Limit Switch Close	From PK-2101 /To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0013 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
234	BZSO-2151	Blowdown Limit Switch Open	From PK-2101 /To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0013 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
235	PIT-2151	Pressure Indicator Transmitter	From PK-2101 / To PL-3101	BK-GCS-PEDCO-120-PR-PI-0013 (1 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
236	PCV-2151	Pressure Control Vavle	From PK-2101 / To PL-3101	BK-GCS-PEDCO-120-PR-PI-0013 (1 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		
237	PCV-2152	Pressure Control Vavle	From PK-2101 /To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0013 (1 of 3)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		
238	FIT-2151	Flow Transmitter	From PK-2101 / To PL-3101	BK-GCS-PEDCO-120-PR-PI-0013 (1 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			D05 Added
239	LIT-2162	Level Indicator Transmitter	TK-2102	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
240	PIT-2161	Pressure Indicator Transmitter	TK-2102	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
241	XF-2161A	Fault Status	P-2103A	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
242	XR-2161A	Running/Stop Status	P-2103A	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
243	XL-2161A	Local / Remote Status	P-2103A	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
244	XSP-2161A	Stop Command	P-2103A	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	DO-NIS-NR	DCS	IRP	*	*	*	*	*	*	*	*						X		
245	XF-2161B	Fault Status	P-2103B	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			

 NISOC				تنگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک							 																				
شماره پیمان: 053 - 073 – 9184				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 15 از 28																			
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه																				
BK				GCS				PEDCO				120				IN				LI				0002				D05			
I/O List For Control System																															
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.								
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.										
246	XR-2161B	Running/Stop Status	P-2103B	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X									
247	XL-2161B	Local / Remote Status	P-2103B	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X									
248	XSP-2161B	Stop Command	P-2103B	BK-GCS-PEDCO-120-PR-PI-0014 (1 of 1)	DO-NIS-NR	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X								
249	XSP-2201A	Stop Command	Air Compressor Package (PK-AC-2203 A/B) / AIR DRYER PACKAGE (PK-DR-2203 A/B)	BK-GCS-PEDCO-120-PR-PI-0015 (1 of 2)	DO-NIS-R	DCS	PK-AC-2203A	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
250	XSS-2201A	Start Command	Air Compressor Package (PK-AC-2203 A/B) / AIR DRYER PACKAGE (PK-DR-2203 A/B)	BK-GCS-PEDCO-120-PR-PI-0015 (1 of 2)	DO-NIS-R	DCS	PK-AC-2203A	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
251	XSP-2201B	Stop Command	Air Compressor Package (PK-AC-2203 A/B) / AIR DRYER PACKAGE (PK-DR-2203 A/B)	BK-GCS-PEDCO-120-PR-PI-0015 (1 of 2)	DO-NIS-R	DCS	PK-AC-2203B	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
252	XSS-2201B	Start Command	Air Compressor Package (PK-AC-2203 A/B) / AIR DRYER PACKAGE (PK-DR-2203 A/B)	BK-GCS-PEDCO-120-PR-PI-0015 (1 of 2)	DO-NIS-R	DCS	PK-AC-2203B	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
253	PIT-2201	Pressure Indicator Transmitter	Air Compressor Package (PK-C-2203 A/B) / AIR DRYER PACKAGE (PK-DR-2203 A/B)	BK-GCS-PEDCO-120-PR-PI-0015 (1 of 2)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X									
254	PCV-2201	Pressure Control Valve	Air Compressor Package (PK-C-2203 A/B) / AIR DRYER PACKAGE (PK-DR-2203 A/B)	BK-GCS-PEDCO-120-PR-PI-0015 (1 of 2)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X								
255	PIT-2203A	Pressure Indicator Transmitter	From V-2203/ TO AIR COMPRESSOR PACKAGE (PK-C-2203A/B)	BK-GCS-PEDCO-120-PR-PI-0015 (2 of 2)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*			X		X									
256	PIT-2203B	Pressure Indicator Transmitter	From V-2203/ TO AIR COMPRESSOR PACKAGE (PK-C-2203A/B)	BK-GCS-PEDCO-120-PR-PI-0015 (2 of 2)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*			X		X									
257	PI-2203A	Pressure Indicator	Air Compressor Package (PK-AC-2203 A/B) / CAPACITY CONTROL SIGNAL / COMPRESSOR LOAD/UNLOAD	BK-GCS-PEDCO-120-PR-PI-0015 (1 of 2)	AO-IS-R	DCS	PK-AC-2203A	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
258	PI-2203B	Pressure Indicator	Air Compressor Package (PK-AC-2203 A/B) / CAPACITY CONTROL SIGNAL / COMPRESSOR LOAD/UNLOAD	BK-GCS-PEDCO-120-PR-PI-0015 (1 of 2)	AO-IS-R	DCS	PK-AC-2203B	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
259	XSP-2211	STOP Command	Air Compressor Package (PK-C-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	DO-NIS-R	DCS	PK-G-2204	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
260	XSS-2211	START Command	Air Compressor Package (PK-C-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	DO-NIS-R	DCS	PK-G-2204	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						
261	PIT-2213	Pressure Indicator Transmitter	From V-2204	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X									
262	PCV-2211	Pressure Control Valve	From V-2204	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*	*	*						X								
263	FIT-2211	Flow Indicator Transmitter	From V-2204	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*					X									
264	TT-2211	Temperature Transmitter	From V-2204	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*					X									
265	PIT-2214	Pressure Indicator Transmitter	From V-2204	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*					X									
266	LIT-2221	Level Indicator Transmitter	V-2202	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X									
267	LIT-2223	Level Indicator Transmitter	LP Flare K.O. Drum and Closed Drum (SU-2201)	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*	*	*		X	X		X									
268	XF-2221A	Fault Status	P-2202-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*						X								
269	XR-2221A	Running/Stop Status	P-2202-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*						X								
270	XL-2221A	Local / Remote Status	P-2202-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*						X								
271	XSS-2221A	Start Command	P-2202-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified						

 NISOC				تکهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک								 															
شماره پیمان: 053 - 073 – 9184				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 16 از 28															
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه																
				BK	GCS	PEDCO	120	IN	LI	0002	D05																
I/O List For Control System																											
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.				
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.						
272	XSP-2221A	Stop Command	P-2202-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
273	XF-2221B	Fault Status	P-2202-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
274	XR-2221B	Running/Stop Status	P-2202-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
275	XL-2221B	Local / Remote Status	P-2202-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
276	XSS-2221B	Start Command	P-2202-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
277	XSP-2221B	Stop Command	P-2202-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
278	XF-2222A	Fault Status	P-2203-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
279	XR-2222A	Running/Stop Status	P-2203-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
280	XL-2222A	Local / Remote Status	P-2203-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
281	XSS-2222A	Start Command	P-2203-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
282	XSP-2222A	Stop Command	P-2203-A	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
283	XF-2222B	Fault Status	P-2203-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
284	XR-2222B	Running/Stop Status	P-2203-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
285	XL-2222B	Local / Remote Status	P-2203-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*	*	*					X					
286	XSS-2222B	Start Command	P-2203-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
287	XSP-2222B	Stop Command	P-2203-B	BK-GCS-PEDCO-120-PR-PI-0017 (2 of 2)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
288	XSP-2231	Stop Command	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DO-NIS-R	DCS	PK-G-2207	*	*	*	*	*	*	*	*	*	*						X		D05 Modified		
289	LSLL-2231	Level Switch Low Low	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*	*	*				X	X					
290	XF-2231A	Fault Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*	*	*						X				
291	XF-2231B	Fault Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*	*	*						X				
292	XF-2231C	Fault Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*	*	*						X				
293	XF-2231D	Fault Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*	*	*						X				
294	XF-2231F	Fault Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*	*	*						X				
295	XR-2231A	Running/Stop Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*	*	*						X				
296	XR-2231B	Running/Stop Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*	*	*						X				

 NISOC			تنگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک						 														
شماره پیمان: 053 - 073 – 9184			I/O LIST FOR CONTROL SYSTEM						شماره صفحه: 17 از 28														
			پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک											سریال	نسخه			
			BK	GCS		120	IN	LI	0002	D05													
I/O List For Control System																							
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.		
297	XR-2231C	Running/Stop Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*						X		
298	XR-2231D	Running/Stop Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*						X		
299	XR-2231F	Running/Stop Status	Corrosion Inhibitor Package (PK-TK-2207) /CORROSION INHIBITOR PACKAGE (PK-2207 A/B/C/D)	BK-GCS-PEDCO-120-PR-PI-0018 (1 of 1)	DI-NIS-NR	PK-G-2207	DCS	*	*	*	*	*	*	*	*						X		
300	LIT-2251	Level Indicator Transmitter	V-2201	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X			X		
301	XF-2251A	Fault Status	P-2201 A	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X		
302	XR-2251A	Running/Stop Status	P-2201 A	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X		
303	XL-2251A	Local / Remote Status	P-2201 A	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X		
304	XSS-2251A	Start Command	P-2201 A	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X	D05 Modified
305	XSP-2251A	Stop Command	P-2201 A	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X	D05 Modified
306	XF-2251B	Fault Status	P-2201 B	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X		
307	XR-2251B	Running/Stop Status	P-2201 B	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X		
308	XL-2251B	Local / Remote Status	P-2201 B	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*						X		
309	XSS-2251B	Start Command	P-2201 B	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X	D05 Modified
310	XSP-2251B	Start Command	P-2201 B	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*							X	D05 Modified
311	PIT-2252	Pressure Indicator Transmitter	From V-2201 to LP Flare Stack	BK-GCS-PEDCO-120-PR-PI-0020 (2 of 3)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		
312	XR-2261	LPG Bottle Inservice	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		D05 Modified
313	XR-2261A	Pilot 1 Status	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
314	XR-2261B	Pilot 2 Status	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
315	XR-2261C	Pilot 3 Status	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
316	XA-2261	Common Fault Alarm	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
317	XF-2261	Auto Ignition Failure	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
318	XA-2262	Burn Back Alarm	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
319	TI-2261A	Temperature Indicator	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	AI-IS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
320	TI-2261B	Temperature Indicator	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	AI-IS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
321	TI-2261C	Temperature Indicator	(Ignition Control Panel IG-2201)	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	AI-IS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		
322	XR-2281	Running/Stop Status	P-2281	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		D05 Modified
323	XF-2281	Fault Status	P-2281	BK-GCS-PEDCO-120-PR-PI-0020 (3 of 3)	DI-NIS-NR	IG-2201-LCP	DCS	*	*	*	*	*	*	*	*						X		D05 Modified
324	LIT-2273	Level Indicator Transmitter	Oily Water Sump (SU-2202)	BK-GCS-PEDCO-120-PR-PI-0021 (1 of 1)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X				X		
325	EZSC-2272	ESDV Limit Switch Close	From Inlet K.O. Drum (V-2105) /TO V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Modified
326	EZSO-2272	ESDV Limit Switch Open	From Inlet K.O. Drum (V-2105) /TO V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*						X		D05 Modified

 NISOC				تنگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																			
شماره پیمان: 053 - 073 – 9184				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 18 از 28											
				پروژه	بسته کاری	صادر کننده	تجهیزات	رشته	نوع مدرک	سریال	نسخه												
				BK	GCS	PEDCO	120	IN	LI	0002	D05												
I/O List For Control System																							
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.		
327	PIT-2272	Pressure Indicator Transmitter	From Inlet K.O. Drum (V-2105) /TO V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
328	PCV-2272	Pressure Control Valve	From Inlet K.O. Drum (V-2105) /TO V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	AO-IS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		
329	LIT-2271	Level Indicator Transmitter	V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
330	PSOV-2271	Solenoid Valve	From V-2205/ To Closed Drum	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
331	XZSC-2271	Limit Switch Close	From V-2205/ To Closed Drum	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
332	XZSO-2271	Limit Switch Open	From V-2205/ To Closed Drum	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			
333	TIT-2271	Temperature Indicator Transmitter	FROM CORROSION INHIBITOR PUMPS (P-2207A/B) /To V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*					X			
334	FIT-2271	Flow Indicator Transmitter	FROM CORROSION INHIBITOR PUMPS (P-2207A/B) /To V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*					X			
335	PIT-2271	Pressure Indicator Transmitter	FROM CORROSION INHIBITOR PUMPS (P-2207A/B) /To V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*					X			
336	PDIT-2271	Diff. Pressure Indicator Transmitter	V-2205	BK-GCS-PEDCO-120-PR-PI-0022 (1 of 1)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X			X			D05 Added
337	LIT-2281	Level Indicator Transmitter	V-2206	BK-GCS-PEDCO-120-PR-PI-0023	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
338	XF-2281A	Fault status	P-2206	BK-GCS-PEDCO-120-PR-PI-0023	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
339	XR-2281A	Running/Stop Status	P-2206	BK-GCS-PEDCO-120-PR-PI-0023	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
340	XSP-2281A	Stop Command	P-2206	BK-GCS-PEDCO-120-PR-PI-0023	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*						X		D05 Modified
341	LIT-2291	Level Indicator Transmitter	TK-2209	BK-GCS-PEDCO-120-PR-PI-0024	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
342	XF-2291	Fault Status	P-2209	BK-GCS-PEDCO-120-PR-PI-0024	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
343	XR-2291	Running/Stop Status	P-2209	BK-GCS-PEDCO-120-PR-PI-0024	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
344	XL-2291	Local / Remote Status	P-2209	BK-GCS-PEDCO-120-PR-PI-0024	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
345	XSP-2291	Stop Command	P-2209	BK-GCS-PEDCO-120-PR-PI-0024	DO-NIS-NR	DCS	IRP	*	*	*	*	*	*	*	*						X		
346	LIT-2293	Level Indicator Transmitter	V-2107	BK-GCS-PEDCO-120-PR-PI-0025	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X	X		X			
347	PIT-2291	Level Indicator Transmitter	V-2107	BK-GCS-PEDCO-120-PR-PI-0025	AI-IS-R	FIELD	DCS	*	*	*	*	*	*	*	*		X			X			
348	XF-2293	Fault Status	P-2104	BK-GCS-PEDCO-120-PR-PI-0025	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
349	XR-2293	Running/Stop Status	P-2104	BK-GCS-PEDCO-120-PR-PI-0025	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
350	XL-2293	Local / Remote Status	P-2104	BK-GCS-PEDCO-120-PR-PI-0025	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			
351	XSP-2293	Stop Command	P-2104	BK-GCS-PEDCO-120-PR-PI-0025	DO-NIS-R	DCS	IRP	*	*	*	*	*	*	*	*						X		D05 Modified
352	LIT-2301A	Level Indicator Transmitter	TK-2301A	BK-GCS-PEDCO-120-SA-PI-0001 (1 of 8)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X	X	X			D05 Modified
353	LIT-2301B	Level Indicator Transmitter	TK-2301B	BK-GCS-PEDCO-120-SA-PI-0001 (1 of 8)	AI-IS-NR	FIELD	DCS	*	*	*	*	*	*	*	*		X	X	X	X			D05 Modified
354	ZSC-2301	Limit Switch Close	FROM EXISTING PLANT T.P-09/ to Fire Water Storage Tank	BK-GCS-PEDCO-120-SA-PI-0001 (1 of 8)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
355	ZSO-2301	Limit Switch Open	FROM EXISTING PLANT T.P-09/ to Fire Water Storage Tank	BK-GCS-PEDCO-120-SA-PI-0001 (1 of 8)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
356	PSOV-2301	Solenoid Valve	FROM EXISTING PLANT T.P-09/ to Fire Water Storage Tank	BK-GCS-PEDCO-120-SA-PI-0001 (1 of 8)	DO-NIS-R	DCS	FIELD	*	*	*	*	*	*	*	*						X		D05 Modified
357	EZSC-3201	ESDV Limit Switch Close	From Dehydration (PK-2101) To Pig Receiver (PR-3201) - Near Pig Launcher	BK-PPL-PEDCO-320-PR-PI-0001 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Modified

 NISOC شماره پیمان: 053 - 073 – 9184			نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																				
			I/O LIST FOR CONTROL SYSTEM									شماره صفحه: 19 از 28											
			پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک	سریال	نسخه													
			BK	GCS	PEDCO	120	IN	LI	0002	D05													
I/O List For Control System																							
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet		ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	INDSTA			COM.
358	EZSO-3201	ESDV Limit Switch Open	From Dehydration (PK-2101) To Pig Receiver (PR-3201) - Near Pig Launcher	BK-PPL-PEDCO-320-PR-PI-0001 (1 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
359	PSOV-3201	Solenoid Valve	From Dehydration (PK-2101) To Pig Receiver (PR-3201) - Near Pig Launcher	BK-PPL-PEDCO-320-PR-PI-0001 (1 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*						X		
-	EZSO-3202	ESDV Limit Switch Close	From Pig Launcher (PR-3201) To Inlet Header (Near Pig Receiver)	BK-PPL-PEDCO-320-PR-PI-0001 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					*			D05 Deleted
-	EZSO-3202	ESDV Limit Switch Open	From Pig Launcher (PR-3201) To Inlet Header (Near Pig Receiver)	BK-PPL-PEDCO-320-PR-PI-0001 (3 of 3)	DI-NIS-NR	FIELD	DCS	*	*	*	*	*	*	*	*					*			D05 Deleted
-	PSOV-3202	Solenoid Valve	From Pig Launcher (PR-3201) To Inlet Header (Near Pig Receiver)	BK-PPL-PEDCO-320-PR-PI-0001 (3 of 3)	DO-NIS-NR	DCS	FIELD	*	*	*	*	*	*	*	*						*		D05 Deleted
360	ESDR 1-PCS	PCS FAILURE	CONTROL ROOM	—	DO-NIS-R	DCS	ESD	*	*	*	*	*	*	*	*						X		D05 Modified
-	ESDR 1-FLR	FLARE IGNITION FAILURE	CONTROL ROOM	—	DO-NIS-R	DCS	ESD	*	*	*	*	*	*	*	*						*		D05 Deleted
361	XOC-LV-Q0A	Open/Close Status (SWGR-Incoming A-Q0A)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
362	XF-LV-Q0A	Fault Status (SWGR-Incoming A-Q0A)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
363	XF-TR-001	Fault Status (Transformer-001)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
364	XOC-LV-Q0B	Open/Close Status (SWGR-Incoming B-Q0B)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
365	XF-LV-Q0B	Fault Status (SWGR-Incoming B-Q0B)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
366	XF-TR-002	Fault Status (Transformer-002)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
367	XOC-LV-Q0C	Open/Close Status (SWGR-Bus Tie C-Q0C)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
368	XF-LV-Q0C	Fault Status (SWGR-Bus Tie C-Q0C)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
369	XOC-LV-Q0E	Open/Close Status (SWGR-DG C.B-Q0E)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
370	XF-LV-Q0E	Fault Status (SWGR-DG C.B-Q0E)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
371	XOC-LV-Q0D	Open/Close Status (SWGR-DG Bus Tie-Q0D)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
372	XF-LV-Q0D	Fault Status (SWGR-DG Bus Tie-Q0D)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (LV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
-	XF-UPS-001-CH01	Fault Status (110V AC UPS-001 (CH01))	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	UPS Charger	DCS	*	*	*	*	*	*	*	*					*			D05 Deleted
-	XF-UPS-001-CH02	Fault Status (110V AC UPS-001 (CH02))	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	UPS Charger	DCS	*	*	*	*	*	*	*	*					*			D05 Deleted
373	XOC-MV-001A-Q2	Open/Close Status (11/0.4 KV SWGR-Transformer feeder-Q2)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
374	XF-MV-001A-Q2	Fault Status (11/0.4 KV SWGR-Transformer feeder-Q2)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified
375	XOC-MV-001A-Q5	Open/Close Status (11 KV SWGR-Spare -Q5)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified

 NISOC				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک						 																	
شماره پیمان: 053 - 073 - 9184				I/O LIST FOR CONTROL SYSTEM						شماره صفحه: 20 از 28																	
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدرک											سریال	نسخه						
BK				GCS		PEDCO		120		IN		LI		0002		D05											
I/O List For Control System																											
ITEM	TAG	DESCRIPTION	SERVICE	D05 P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet		ALARM				FUNCTION		REMARK	REV.					
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA			COM.				
376	XF-MV-001A-Q5	Fault Status (11 KV SWGR-Spare -Q5)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
377	XOC-MV-001B-Q2	Open/Close Status (11/0.4 KV SWGR-Transformer feeder-Q2)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
378	XF-MV-001B-Q2	Fault Status (11/0.4 KV SWGR-Transformer feeder-Q2)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
379	XOC-MV-001B-Q4	Open/Close Status (11/3.3 KV SWGR-Transformer feeder-Q4)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
380	XF-MV-001B-Q4	Fault Status (11/3.3 KV SWGR-Transformer feeder-Q4)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
381	XOC-MV-001B-Q5	Open/Close Status (11KV SWGR-Spare -Q5)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
382	XF-MV-001B-Q5	Fault Status (11KW SWGR-Spare -Q5)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
383	XOC-MV-001C-Q3	Open/Close Status (3.3 KV SWGR-Fire Pump -Q3)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
384	XF-MV-001C-Q3	Fault Status (3.3 KV SWGR-Fire Pump -Q3)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
385	XL-ATS	Auto/Manual Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP	DCS	*	*	*	*	*	*	*	*					X			D05 Modified				
386	XS-2100A	Time Synchron Signal for C-2101A	CONTROL ROOM	BK-GCS-HY-120-PR-PI-0001 (9A)	DO-NIS-R	DCS	UCP-GC-2101A	*	*	*	*	*	*	*	*						X		D05 Added				
387	XS-2100B	Time Synchron Signal for C-2101B	CONTROL ROOM	BK-GCS-HY-120-PR-PI-0001 (9B)	DO-NIS-R	DCS	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Added				
388	XS-2100C	Time Synchron Signal for C-2101C	CONTROL ROOM	BK-GCS-HY-120-PR-PI-0001 (9C)	DO-NIS-R	DCS	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		D05 Added				

 NISOC				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک								 											
شماره پیمان:				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 21 از 28											
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدارک	سریال	نسخه												
053 - 073 – 9184				BK	GCS	PEDCO	120	IN	LI	0002	D05												
I/O List For UCP-C-2101 (NOTE 5)																							
ITEM	TAG	DESCRIPTION	SERVICE	P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet		ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	INDSTA			COM.
	PSOV-2110	Solenoid Valve	FROM 1ST STAGE GAS COMPRESSION-SUCTION MANIFOLD /To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0005	DO-NIS-NR	UCP-GC-2101A	FIELD	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
	BZSC-2110	Limit Switch Close	FROM 1ST STAGE GAS COMPRESSION-SUCTION MANIFOLD /To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0005	DI-NIS-NR	FIELD	UCP (Note 2)	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
	BZSO-2110	Limit Switch Open	FROM 1ST STAGE GAS COMPRESSION-SUCTION MANIFOLD /To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0005	DI-NIS-NR	FIELD	UCP (Note 2)	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
	PSOV-2121A	Solenoid Valve	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DO-NIS-NR	UCP-GC-2101A	FIELD	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
	XZSC-2121A	Limit Switch Close	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
	XZSO-2121A	Limit Switch Open	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
1	PSOV-2123A	Solenoid Valve	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD /To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DO-NIS-NR	UCD (Note 1)	FIELD	*	*	*	*	*	*	*	*	*						X	
2	XZSC-2123A	Limit Switch Close	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD /To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
3	XZSO-2123A	Limit Switch Open	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD /To V-2101-A	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
4	PI-2121A	Pressure Indicator	Outlet V-2101-A /to 1st Stage Compressor (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	AHS-R	DCS	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
5	PCV-2123A	Pressure Control Valve	Outlet V-2101-A /to 1st Stage Compressor (C-2101A)	BK-GCS-PEDCO-120-PR-PI-0006 (1 of 3)	AO-IS-R	UCP-GC-2101A	FIELD	*	*	*	*	*	*	*	*	*						X	
6	FIT-2121A	Flow Indicator Transmitter	1st Stage Gas Compressor Train A Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
7	TIT-2122A	Temperature Indicator Transmitter	1st Stage Gas Compressor Train A Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
8	PDIT-2122A	Differential Pressure Indicator Transmitter	2nd Stage Gas Compressor Train A Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
9	PIT-2123A	Pressure Indicator Transmitter	1st Stage Gas Compressor Train A Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
10	TIT-2123A	Temperature Indicator Transmitter	1st Stage Gas Compressor Train A Discharge Line	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
11	PIT-2124A	Pressure Indicator Transmitter	1st Stage Gas Compressor Train A Discharge Line	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
	PSOV-2134A	Solenoid Valve	From 1ST Stage Air Cooler (AE-2101A) To LP Flare-Header	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	DO-NIS-NR	UCP-GC-2101A	FIELD	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
	BZSC-2134A	Blowdown Limit Switch Close	From 1ST Stage Air Cooler (AE-2101A) To LP Flare-Header	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
	BZSO-2134A	Blowdown Limit Switch Open	From 1ST Stage Air Cooler (AE-2101A) To LP Flare-Header	BK-GCS-PEDCO-120-PR-PI-0009 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	2	2	2	2	2	2	2	2	2						X	D05 Deleted (Moved to DCS)
12	FIT-2131A	Flow Indicator Transmitter	2nd Stage Gas Compressor Train A Suction Line	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
13	TIT-2132A	Temperature Indicator Transmitter	2nd Stage Gas Compressor Train A Suction Line	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
14	PDIT-2132A	Differential Pressure Indicator Transmitter	2nd Stage Gas Compressor Train A Suction Line	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
15	PIT-2132A	Pressure Indicator Transmitter	2nd Stage Gas Compressor Train A Suction Line	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
16	TIT-2133A	Temperature Indicator Transmitter	2nd Stage Gas Compressor Train A Discharge Line	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	
17	PIT-2133A	Pressure Indicator Transmitter	2nd Stage Gas Compressor Train A Discharge Line	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	AHS-R	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*	*						X	

 NISOC		نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض																					
		احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																					
		I/O LIST FOR CONTROL SYSTEM																					
شماره پیمان:		پروژه	بسته کاری	صادر کننده	تجهیزات	رشته	نوع مدارک	سریال	نسخه	شماره صفحه: 22 از 28													
053 - 073 - 9184		BK	GCS	PEDCO	120	IN	LI	0002	D05														
I/O List For UCP-C-2101 (NOTE 5)																							
ITEM	TAG	DESCRIPTION	SERVICE	P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet		ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	INDSTA			COM.
	PSOV-2132A	Solenoid Valve	From Methanol Header To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DO-NIS-NR	UCP-GC-2101A	FIELD	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	BZSC-2132A	Blowdown Limit Switch Close	From Methanol Header To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	BZSO-2132A	Blowdown Limit Switch Open	From Methanol Header To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	PSOV-2133A	Solenoid Valve	From AE-2102-A To Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DO-NIS-NR	UCP-GC-2101A	FIELD	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	BZSC-2133A	Blowdown Limit Switch Close	From AE-2102-A To Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	BZSO-2133A	Blowdown Limit Switch Open	From AE-2102-A To Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (1 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101A	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	XGC-MV-001A-Q3	Open/Close Status (SWGR Gas Compressor A-2101A-Q3)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	UCP-GC-2101A	*	*	*	*	*	*	*	*						*		D05 Deleted
18	XST-2224A	Start Command	11 KV SWGR-MV-001A-Q3 Gas Compressor-C-2101A	ELECTRICAL I/O SIGNAL LIST	DO-NIS-NR	UCP-GC-2101A	IRP (MV SWG)	*	*	*	*	*	*	*	*						X		D05 Added
19	XSP-2224A	Stop Command	11 KV SWGR-MV-001A-Q3 Gas Compressor-C-2101A	ELECTRICAL I/O SIGNAL LIST	DO-NIS-NR	UCP-GC-2101A	IRP (MV SWG)	*	*	*	*	*	*	*	*						X		D05 Added
20	XL-2224A	Running Status	11 KV SWGR-MV-001A-Q3 Gas Compressor-C-2101A	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	UCP-GC-2101A	*	*	*	*	*	*	*	*					X			D05 Added
21	XA-2224A	Fault Status	11 KV SWGR-MV-001A-Q3 Gas Compressor-C-2101A	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	UCP-GC-2101A	*	*	*	*	*	*	*	*					X			D05 Modified
	PSOV-2121B	Solenoid Valve	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DO-NIS-NR	UCP-GC-2101B	FIELD	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	XZSC-2121B	Limit Switch Close	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	XZSO-2121B	Limit Switch Open	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
22	PSOV-2123B	Solenoid Valve	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD To V-2101-B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DO-NIS-NR	UCD (Note 1)	FIELD	*	*	*	*	*	*	*	*						X		
23	XZSC-2123B	Limit Switch Close	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD To V-2101-B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
24	XZSO-2123B	Limit Switch Open	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD To V-2101-B	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
25	PI-2121B	Pressure Indicator	Outlet V-2101-A /to 1st Stage Compressore (C-2101B)	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	AI-IS-R	DCS	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
26	PCV-2123B	Pressure Control Valve	Outlet V-2101-A /to 1st Stage Compressore (C-2101B)	BK-GCS-PEDCO-120-PR-PI-0006 (2 of 3)	AO-IS-R	UCP-GC-2101B	FIELD	*	*	*	*	*	*	*	*						X		
27	FIT-2121B	Flow Indicator Transmitter	1st Stage Gas Compressor Train B Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
28	TIT-2122B	Temperature Indicator Transmitter	1st Stage Gas Compressor Train B Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
29	PDIT-2122B	Differential Pressure Indicator Transmitter	2nd Stage Gas Compressor Train B Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
30	PIT-2123B	Pressure Indicator Transmitter	1st Stage Gas Compressor Train B Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
31	TIT-2123B	Temperature Indicator Transmitter	1st Stage Gas Compressor Train B Discharge Line	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
32	PIT-2124B	Pressure Indicator Transmitter	1st Stage Gas Compressor Train B Discharge Line	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*					X			
	PSOV-2134B	Solenoid Valve	From 1ST Stage Air Cooler (AE-2101B) To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	DO-NIS-NR	UCP-GC-2101B	FIELD	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)
	BZSC-2134B	Blowdown Limit Switch Close	From 1ST Stage Air Cooler (AE-2101B) To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						*		D05 Deleted (Moved to DCS)

 NISOC				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض							 گسترش و توسعه  IRIS  TGS												
شماره پیمان:				I/O LIST FOR CONTROL SYSTEM											شماره صفحه: 23 از 28								
				پروژه	بسته کاری	صادر کننده	تهیهات	رشته	نوع مدارک	سرپال	نسخه												
053 - 073 - 9184				BK	GCS	PEDCO	120	IN	LI	0002	D05												
I/O List For UCP-C-2101 (NOTE 5)																							
ITEM	TAG	DESCRIPTION	SERVICE	P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet		ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	INDSTA			COM.
	BZSO-2134B	Blowdown Limit Switch Open	From 1ST Stage Air Cooler (AE-2101B) To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0009 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
33	FIT-2131B	Flow Indicator Transmitter	2nd Stage Gas Compressor Train B Suction Line	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		
34	TIT-2132B	Temperature Indicator Transmitter	2nd Stage Gas Compressor Train B Suction Line	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		
35	PDIT-2132B	Differential Pressure Indicator Transmitter	2nd Stage Gas Compressor Train B Suction Line	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		
36	PIT-2132B	Pressure Indicator Transmitter	2nd Stage Gas Compressor Train B Suction Line	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		
37	TIT-2133B	Temperature Indicator Transmitter	2nd Stage Gas Compressor Train B Discharge Line	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		
38	PIT-2133B	Pressure Indicator Transmitter	2nd Stage Gas Compressor Train B Discharge Line	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	AI-IS-R	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		
	PSOV-2132B	Solenoid Valve	From Methanol Header To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DO-NIS-NR	UCP-GC-2101B	FIELD	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
	BZSC-2132B	Blowdown Limit Switch Close	From Methanol Header To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
	BZSO-2132B	Blowdown Limit Switch Open	From Methanol Header To LP Flare Header	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
	PSOV-2133B	Solenoid Valve	From AE-2102-B To Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DO-NIS-NR	UCP-GC-2101B	FIELD	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
	BZSC-2133B	Blowdown Limit Switch Close	From AE-2102-B To Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
	BZSO-2133B	Blowdown Limit Switch Open	From AE-2102-B To Gas Compression Discharge Drum (V-2103)	BK-GCS-PEDCO-120-PR-PI-0011 (2 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
	XOC-MV-001A-Q4	Close Status (SWGR-Gas Compressor-C-2101)	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Deleted
39	XST-2224B	Start Command	11 KV SWGR-MV-001A-Q4 Gas Compressor-C-2101B	ELECTRICAL I/O SIGNAL LIST	DO-NIS-NR	UCP-GC-2101B	IRP (MV SWG)	*	*	*	*	*	*	*	*						X		D05 Added
40	XSP-2224B	Stop Command	11 KV SWGR-MV-001A-Q4 Gas Compressor-C-2101B	ELECTRICAL I/O SIGNAL LIST	DO-NIS-NR	UCP-GC-2101B	IRP (MV SWG)	*	*	*	*	*	*	*	*						X		D05 Added
41	XL-2224B	Running Status	11 KV SWGR-MV-001A-Q4 Gas Compressor-C-2101B	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Added
42	XA-2224B	Fault Status	11 KV SWGR-MV-001A-Q4 Gas Compressor-C-2101B	ELECTRICAL I/O SIGNAL LIST	DI-NIS-NR	IRP (MV SWG)	UCP-GC-2101B	*	*	*	*	*	*	*	*						X		D05 Modified
	PSOV-2121C	Solenoid Valve	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DO-NIS-NR	UCP-GC-2101C	FIELD	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
	XZSC-2121C	Limit Switch Close	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
	XZSO-2121C	Limit Switch Open	FROM 1ST STAGE RECYCLING VALVE LINE To V-2101-C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		D05 Deleted (Moved to DCS)
43	PSOV-2123C	Solenoid Valve	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD To V-2101-C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DO-NIS-NR	UCD (Note 1)	FIELD	*	*	*	*	*	*	*	*						X		
44	XZSC-2123C	Limit Switch Close	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD To V-2101-C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		
45	XZSO-2123C	Limit Switch Open	FROM 1ST STAGE GAS COMPRESSION SUCTION MANIFOLD To V-2101-C	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	DI-NIS-NR	FIELD	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		
46	PI-2121C	Pressure Indicator	Outlet V-2101-A To 1st Stage Compressore (C-2101C)	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	AHS-R	DCS	UCP-GC-2101C	*	*	*	*	*	*	*	*						X		
47	PCV-2123C	Pressure Control Valve	Outlet V-2101-A To 1st Stage Compressore (C-2101C)	BK-GCS-PEDCO-120-PR-PI-0006 (3 of 3)	AO-IS-R	UCP-GC-2101C	FIELD	*	*	*	*	*	*	*	*						X		
48	FIT-2121C	Flow Indicator Transmitter	1st Stage Gas Compressor Train C Suction Line	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	AHS-R	FIELD	UCP	*	*	*	*	*	*	*	*						X		

 NISOC				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																				
شماره پیمان:				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 25 از 28												
				پروژه	بسته کاری	صادرکننده	تجهیزات	رشته	نوع مدارک	سریال	نسخه													
053 - 073 - 9184				BK	GCS	PEDCO	120	IN	LI	D05														
SOFTWARE DATA-LINK LIST FOR UCP																						D05		
ITEM	TAG	DESCRIPTION	SERVICE	P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.			
UCP-C-2101A: GAS COMPRESSOR A (NOTE 7)																								
1	XF-2121A	Fault Status	Gas Compressor C-2101 Train A	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
2	XR-2123A	Running/Stop Status	Gas Compressor C-2101 Train A	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
3	FIA-2121A	Flow Indicator	Gas Compressor C-2101 Train A 1st Stage Suction	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
4	PIA-2123A	Pressure Indicator	Gas Compressor C-2101 Train A 1st Stage Suction	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
5	TIA-2122A	Temperature Indicator	Gas Compressor C-2101 Train A 1st Stage Suction	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
6	PIA-2124A	Pressure Indicator	Gas Compressor C-2101 Train A1st Stage Discharge	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*			X			X			D05 Modified
7	TIA-2123A	Temperature Indicator	Gas Compressor C-2101 Train A1st Stage Discharge	BK-GCS-PEDCO-120-PR-PI-0007 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
8	FIA-2131A	Flow Indicator	Gas Compressor C-2101 Train A 2nd Stage Suction	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
9	PIA-2132A	Pressure Indicator	Gas Compressor C-2101 Train A 2nd Stage Suction	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
10	TIA-2132A	Temperature Indicator	Gas Compressor C-2101 Train A 2nd Stage Suction	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
11	PIA-2133A	Pressure Indicator	Gas Compressor C-2101 Train A 2nd Stage Discharge	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
12	TIA-2133A	Temperature Indicator	Gas Compressor C-2101 Train A 2nd Stage Discharge	BK-GCS-PEDCO-120-PR-PI-0010 (1 of 3)	Data-Link Software	UCP-C-2101A	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
UCP-C-2101B: GAS COMPRESSOR B (NOTE 7)																								
13	XF-2121B	Fault Status	Gas Compressor C-2101 Train B	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
14	XR-2123B	Running/Stop Status	Gas Compressor C-2101 Train B	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
15	FIA-2121B	Flow Indicator	Gas Compressor C-2101 Train B 1st Stage Suction	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
16	PIA-2123B	Pressure Indicator	Gas Compressor C-2101 Train B 1st Stage Suction	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
17	TIA-2122B	Temperature Indicator	Gas Compressor C-2101 Train B 1st Stage Suction	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
18	PIA-2124B	Pressure Indicator	Gas Compressor C-2101 Train B1st Stage Discharge	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
19	TIA-2123B	Temperature Indicator	Gas Compressor C-2101 Train B1st Stage Discharge	BK-GCS-PEDCO-120-PR-PI-0007 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
20	FIA-2131B	Flow Indicator	Gas Compressor C-2101 Train B 2nd Stage Suction	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
21	PIA-2132B	Pressure Indicator	Gas Compressor C-2101 Train B 2nd Stage Suction	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
22	TIA-2132B	Temperature Indicator	Gas Compressor C-2101 Train B 2nd Stage Suction	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
23	PIA-2133B	Pressure Indicator	Gas Compressor C-2101 Train B 2nd Stage Discharge	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
24	TIA-2133B	Temperature Indicator	Gas Compressor C-2101 Train B 2nd Stage Discharge	BK-GCS-PEDCO-120-PR-PI-0010 (2 of 3)	Data-Link Software	UCP-C-2101B	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
UCP-C-2101C: GAS COMPRESSOR C (NOTE 7)																								
25	XF-2121C	Fault Status	Gas Compressor C-2101 Train C	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	Data-Link Software	UCP-C-2101C	DCS	*	*	*	*	*	*	*	*						X			D05 Added
26	XR-2123C	Running/Stop Status	Gas Compressor C-2101 Train C	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	Data-Link Software	UCP-C-2101C	DCS	*	*	*	*	*	*	*	*						X			D05 Modified
27	FIA-2121C	Flow Indicator	Gas Compressor C-2101 Train C 1st Stage Suction	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	Data-Link Software	UCP-C-2101C	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified
28	PIA-2123C	Pressure Indicator	Gas Compressor C-2101 Train C 1st Stage Suction	BK-GCS-PEDCO-120-PR-PI-0007 (3 of 3)	Data-Link Software	UCP-C-2101C	DCS	*	*	*	*	*	*	*	*		X	X			X			D05 Modified



احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک



شماره صفحه: 27 از 28

زہ پیمان:

053 - 073-9184

٢

پسته کاری

0.2

تسهيلات

مدرک

سریال

نسخه

SOFTWARE DATA-LINK LIST FOR UCP

D05

ITEM	TAG	DESCRIPTION	SERVICE	P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET				Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.	
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA			COM.
58	XR-2211	Running/Stop Status	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*					X		
59	XF-2211	Fault Status	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*					X		
60	XA-2211	Availibility	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*					X		
61	TAH-2211	Temperature High Alarm	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*	X				X		
62	PIA-2211	Pressure Indicator Transmitter	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*		X			X		D05 Modified
	PAH-2211	Pressure Low Alarm	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*	*				*		D05 Deleted
63	PDIA-2211	Dif. Pressure Indicator Transmitter	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*	X				X		
	XR-2212	Running/Stop Status	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*					*		D05 Deleted
	XF-2212	Fault Status	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*					*		D05 Deleted
64	PDIA-2212	Dif. Pressure Indicator Transmitter	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*	X				X		
65	AIA-2212	Humidity Analyzer	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	PK-G-2204	DCS	*	*	*	*	*	*	*	*	*	X				X		
66	AIA-2213	Humidity Analyzer	Air Compressor Package (PK-G-2204)/NITROGEN PACKAGE (PK-G-2204)/ NITROGEN RECEIVER (V-2204)	BK-GCS-PEDCO-120-PR-PI-0016 (1 of 1)	Data-Link Software	FIELD	DCS	*	*	*	*	*	*	*	*	*	X				X		
110V AC UPS-001 (CH01)																							
67	XO-UPS-001-CH01	On/Off Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*	*							
68	XC-UPS-001-CH01	Current Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*	*							
69	XV-UPS-001-CH01	Voltage Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*	*							
110V AC UPS-001 (CH02)																							
70	XO-UPS-001-CH02	On/Off Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*	*							
71	XC-UPS-001-CH02	Current Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*	*							
72	XV-UPS-001-CH02	Voltage Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*	*							
24V DC UPS-002 (CH01)																							

 NISOC				نگهداشت و افزایش تولید میدان نفتی بینک سطح الارض احداث ردیف تراکم گاز در ایستگاه جمع آوری بینک																			
شماره پیمان: 053 - 073 - 9184				I/O LIST FOR CONTROL SYSTEM								شماره صفحه: 28 از 28											
				پروژه	بسته کاری	صادرکننده	تجهیزات	رشته	نوع مدارک	سریال	نسخه												
				BK	GCS	PEDCO	120	IN	LI	0002	D05												
SOFTWARE DATA-LINK LIST FOR UCP																D05							
ITEM	TAG	DESCRIPTION	SERVICE	P&ID / Reference Document	I/O TYPE	FROM	TO	SYSTEM CABINET					Marshalling Cabinet			ALARM				FUNCTION		REMARK	REV.
								CABINET NO.	RACK	SLOT	CH.	ADD.	CABINET NO.	TB NO.	ADD.	HH	H	L	LL	IND/STA	COM.		
73	XO-UPS-002-CH01	On/Off Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
74	XC-UPS-002-CH01	Current Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
75	XV-UPS-002-CH01	Voltage Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
76	XF-UPS-002-CH01	Fault Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
24V DC UPS-002 (CH02)																							
77	XO-UPS-002-CH02	On/Off Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
78	XC-UPS-002-CH02	Current Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
79	XV-UPS-002-CH02	Voltage Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
80	XF-UPS-002-CH02	Fault Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
110V DC CHARGER-001 (CH01)																							
81	XO-CHG-001-CH01	On/Off Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
82	XC-CHG-001-CH01	Current Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
83	XV-CHG-001-CH01	Voltage Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
84	XF-CHG-001-CH01	Fault Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
110V DC CHARGER-001 (CH02)																							
85	XO-CHG-001-CH02	On/Off Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
86	XC-CHG-001-CH02	Current Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
87	XV-CHG-001-CH02	Voltage Sample	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
88	XF-CHG-001-CH02	Fault Status	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	UPS Charger	DCS	*	*	*	*	*	*	*	*								
400 V SWGR-INCOMING																							
89	XM-LV-IN1	Multifunction Meter	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	IRP	DCS	*	*	*	*	*	*	*	*						X		
90	XM-LV-IN2	Multifunction Meter	CONTROL ROOM	ELECTRICAL I/O SIGNAL LIST	Data-Link Software	IRP	DCS	*	*	*	*	*	*	*	*						X		